ULTRASONIC SENSOR

HC-SR04

BESTIN AUTOMATION

An ISO 9001:2015 certified company

Proprietor: Amritpal Singh

Introduction to Ultrasonic sensor

The HC-SR04 is an affordable and easy to use distance measuring sensor which has a range from 2cm to 400cm (about an inch to 13 feet).

The sensor is composed of two ultrasonic transducers. One is transmitter which outputs ultrasonic sound pulses and the other is receiver which listens for reflected waves. It's basically a SONAR which is used in submarines for detecting underwater objects.


Tinkercad Features



Operating Voltage	5V DC
Operating Current	15mA
Operating Frequency	40KHz
Min Range	2cm / 1 inch
Max Range	400cm / 13 feet
Accuracy	3mm
Measuring Angle	<15°
Dimension	45 x 20 x 15mm


Ultrasonic Sensor pinout


The sensor has 4 pins. VCC and GND go to 5V and **GND** pins on the Arduino, and the *Trig* and *Echo* go to any digital Arduino pin. Using the Trig pin we send the ultrasound wave from the transmitter, and with the Echo pin we listen for the reflected signal.



Working of ultrasonic sensor

It emits an ultrasound at 40 000 Hz which travels through the air and if there is an object or obstacle on its path It will bounce back to the module. Considering the travel time and the speed of the sound you can calculate the distance.





In order to generate the ultrasound we need to set the Trig pin on a High State for 10 µs. That will send out an 8 cycle ultrasonic burst which will travel at the speed of sound. The Echo pins goes high right away after that 8 cycle ultrasonic burst is sent, and it starts listening or waiting for that wave to be reflected from an object.

If there is no object or reflected pulse, the Echo pin will time-ou after 38ms and get back to low state.

If we receive a reflected pulse, the Echo pin will go down sooner than those 38ms. According to the amount of time the Echo pin was HIGH, we can determine the distance the sound wave traveled, thus the distance from the sensor to the object.

For that purpose we are using the following basic formula for calculating distance:


Distance = Speed x Time

We actually know both the speed and the time values. The time is the amount of time the Echo pin was HIGH, and the speed is the speed of sound which is 340m/s. There's one additional step we need to do, and that's divide the end result by 2. and that's because we are measuring the duration the sound wave needs to travel to the object and bounce back.

Let's say the Echo pin was HIGH for 2ms. If we want the get the distance result in cm, we can convert the speed of sound value

from 340m/s to 34cm/ms. For example: Receiver pulse duration - Time = 1.5ms Speed of sound - Speed = 340m/s = 34cm/s $Distance = (Speed \times Time) / 2$ Distance = $(34cm/ms \times 1.5ms)/2 = 25.5cm$

How to Connect HC-SR04 Ultrasonic Sensor to Arduino



Code:

```
const int trigPin = 9;
const int echoPin = 10;
long duration;
int distance;
void setup() {
pinMode(trigPin, OUTPUT);
pinMode(echoPin, INPUT);
Serial.begin(9600);
void loop() {
digitalWrite(trigPin, LOW);
delayMicroseconds(2);
digitalWrite(trigPin, HIGH);
delayMicroseconds(10);
digitalWrite(trigPin, LOW);
duration = pulseIn(echoPin, HIGH);
distance = duration * 0.034 / 2
Serial.print("Distance: ");
Serial.println(distance); }
```

Thanks for your attention!

BESTIN AUTOMATION

An ISO 9001:2015 certified company